


Hybrid inverter User Manual

GEN-LB-EU 7-10K



Copyright© 2026 Lux Power Technology Co., Ltd. All Rights Reserved. This manual, protected by the copyright and intellectual property rights of Lux Power Technology, may not be modified, copied, or reproduced without prior written permission. Brands and trademarks mentioned belong to their respective owners. Read carefully for product reliability and warranty eligibility. For warranty details, refer to Lux Power Technology Limited Warranty. Intended for professional service providers; no statements constitute an express or implied warranty.

Descriptions may contain predictive statements; differences may occur. Provided for reference, subject to change without notice by Lux Power Technology.



Website



YouTube



Facebook

 www.luxpowertek.com



Scan to download

Table Of Contents

About This Manual	1
1. Safety	1
1.1 Safety Instruction	1
2. Brief Introduction	4
2.1 System Solution	4
3. Installation	5
3.1 Packaging List	5
3.2 Location Selection and Installation	6
3.2.1 Requirements for installation location	6
3.2.2 Installing the inverter	7
3.3 Connection Overview	9
3.3.1 System connection	9
3.4 PV Connection	11
3.5 Battery Connection	13
3.5.1 Battery power cable connection	13
3.5.2 Battery communication cable connection	15
3.6 Grid&EPS load Connection	16
3.6.1 Grid type selection	16
3.6.2 Grid and EPS load connection for single-phase service	16
3.6.3 AC cable connection	17
3.6.4 CT/Meter connection	19
3.7 Working with Generator	21
3.7.1 Generator system connection	21
3.7.2 Generator Startup and stop settings	23
3.8 AC Coupling Installation Connection	23
3.9 Parallel System Connection	25
3.9.1 Connection for paralleling system	25
3.10 Monitor System Setup	28

3.10.1 Wifi/2G/4G/WLAN dongle connection	28
3.10.2 Setup the Monitor system	29
3.10.3 Set homewifi password to dongle	30
3.10.4 Third party RS485 communication	31
4. Operation Guide	32
4.1 Operation Mode	32
4.1.1 Self-usage mode (Default)	32
4.1.2 Charge first mode	33
4.1.3 AC charge mode	34
4.1.4 Grid peak-shaving Function	34
4.1.5 Smart load Function	35
4.2 LCD Display	35
4.2.1 Viewing information and alarm/fault record	35
4.2.2 Setting parameters	37
4.3 Start-up and shut down the inverter	40
4.3.1 Start up the inverter	40
4.3.2 Shut down the inverter	40
5. Troubleshooting & Maintenance	40
5.1 Regular Maintenance	40
5.2 LED Displays	41
5.3 Troubleshooting Based on LCD Displays.	41
5.4 Fan replacement	41

Revision History

Version	Date	Description
UM-GEN02002	2024.07.04	First official release.

Safety

1.1 Safety Instruction

General Safety Instructions

The inverter has been designed and tested strictly according to international safety regulations. Read all safety instructions carefully prior to any work and observe them at all times when working on or with the inverter. The operator must be qualified personnel and the installation must be capable with relevant national or international standards or regulations.

Incorrect operation or work may cause:

- injury or death to the operator or a third party
- damage to the inverter and other properties belonging to the operator or a third party.

Important Safety Notifications

There are many safety issues need to be carefully notified before, during and after the installation, and also in future operation and maintenance, following is important safety notifications to operator, owner and user of this product in appropriate usage.

DANGER

Dangers of High Voltages and Large Current

- Beware of high PV voltage. Please turn-off the DC switch of PV Panel output before and during the installation to avoid electric shock.
- Beware of high grid voltage. Please turn-off the AC switch of grid connection before and during the installation to avoid electric shock.
- Beware of large current of the battery output. Please turn-off the battery module before and during the installation to avoid electric shock.
- Do not open the inverter when it's working to avoid electric shock and damages from live voltage and current from the system.
- Do not operate the inverter when it's working, only the LCD and buttons can be touched in limited cases by qualified personnel, other parts of the inverter can be touched when the inverter is under a safe state (e.g. fully shut-down).
- Do not connect or disconnect any connections (PV, battery, grid, communication etc.) of the inverter when it's working.
- Make sure the inverter is well grounding, an operator should make sure himself is good protected by reasonable and professional insulation measurements (e.g. personal protective equipment (PPE)).
- Inspect relevant existed wiring on-site of the installation is under good condition before installation, operation or maintenance.
- Inspect the connections are good between inverter and PV, battery and grid during installation to prevent damages or injuries caused by bad connections.

⚠ WARNING**Avoid Misoperation and Inappropriate Usage**

- All the work of this product (system design, installation, operation, setting, configuration and maintenance must be carried out by qualified personnel as required.
- All connections must be in accordance with local and national regulations and standards.
- Only when permitted by utility grid, the inverter and system can interconnected with the utility grid. All the warning labels or nameplates on the inverter must be clearly visible and must not be removed, covered or pasted.

The installation should choose a right position and location as required in this manual with

- consideration to safety of users' in future operation.

Please keep the children away from touching or misoperation the inverter and relevant system.

- Beware of burning hurt, the inverter and some parts of the system could be hot when working,
- Beware of burning hurt, the inverter and some parts of the system could be hot when working, please do not touch the inverter surface or most of the parts when they are working. During inverter is in working, only the LCD and buttons could be touched.


● NOTICE

- Please carefully read this manual before any work carried out on this inverter, after the installation, please keep this manual carefully stored and easy to access at any time.
- Qualified personnel must undergo training in electrical system installation and commissioning, including hazard management. They should possess knowledge of the manual and related documents. Installers or operators are expected to be regulations and directives.

2. Brief Introduction

2.1 System Solution


This product and relevant system is suitable for following system applications (system diagram):



3. Installation

3.1 Packing List


Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items in the package:

					
Hybrid Inverter ×1	User Manual ×1	RJ45 Terminal ×4	Wi-Fi Module ×1	Communication Port Cover ×1	Expansion Screw ×4
					
Wall-mounted bracket ×1	Disassembly Tool (for connector) ×1	Cross Head M3*16 ×16 M4*2 ×2	PV quick-connect terminal/Female ×4	PV quick-connect terminal/male ×4	
					
PV Terminal Male Core ×4	PV Terminal Female Core ×4	CT ×1	Grid Connector ×1	EPS Connector ×1	GEN Connector ×1
					
Battery Communication cable L= 2m ×1 (Orange)	Parallel Communication cable L=2m ×1 (grey)	Battery Connector Waterproof Cover ×1			


3.2 Location Selection and Installation

3.2.1 Requirements for installation location


- The wall for mounting should be strong enough to bear the weight of inverter.
- Please maintain the minimum clearances below for adequate heat dissipation.



- Never install the inverter in a place with direct sunlight, rain or snow. Please refer to below figure and select a well shaded place or install a shed to protect the inverter from direct sunlight, rain and snow etc. Protect the LCD screen from excessive UV exposure




d. The inverter should be installed upright on a vertical surface.





3.2.2 Install the inverter

The inverter is wall-mounted type, should be installed on a vertical, solid mounting surface, such as wood studs, brick or concrete wall. Two or more persons may be needed to install the inverter due to its weight.





The mounting steps are as below: (Use brick wall as example)



Step 1. Mark the positions of drill holes with the mounting bracket, then drill 4 holes of 8mm (5/16inch) diameter and make sure the depth of the holes is deeper than 50mm(2inch).



Step 2. Install the expansion bolts into the holes and tighten them, then use the corresponding nuts and washers (packaged together with the expansion bolts) to install and fix the wall-mounting bracket on the wall



Step 3. Hang the inverter onto the wall-mounting bracket and lock the inverter on the wall using 2 self-tapping screws on the top of the inverter.



For installation on wood studs


Fasten the mounting bracket on the studs with 4 wood screws, then hang the inverter onto the bracket and lock the inverter on the wall with 2 self-tapping screws.

Please note that the wood screws and self-tapping screws are not provided with the inverter. Installers need to prepare the screws before installation. The mounting steps are as below: (Use brick wall as example)

3.3 Connection Overview


3.3.1 System Connection

The system connection diagram is as below:



Please prepare the breakers before connetion, breakers selection recommendation for both DC and AC

Inverter model	7K	8K	10K
PV Breakers(2Px4)	MPPT1 string 1: 600V/20A MPPT1 string 2: 600V/20A MPPT2 string 1: 600V/20A MPPT2 string 2: 600V/20A	MPPT1 string 1: 600V/20A MPPT1 string 2: 600V/20A MPPT2 string 1: 600V/20A MPPT2 string 2: 600V/20A	MPPT1 string 1: 600V/20A MPPT1 string 2: 600V/20A MPPT2 string 1: 600V/20A MPPT2 string 2: 600V/20A
Battery Breaker(2P)	100V/300A	100V/300A	100V/300A
Main Breaker(2P)	100A/230Vac	100A/230Vac	100A/230Vac
Load Breaker(2P)	63A/230Vac	63A/230Vac	63A/230Vac
Generator Breaker	63A/230V	63A/230V	63A/230V



a	Battery communication port(CAN&RS485) please check Chapter 3.5.2 for Pin definition
b	CT port: Please check Chapter 3.6.4 for CT connection
c	INV 485: Debugging port
d	Parallel communication port please check Chapter 3.9 for Parallel connection
e	GEN(NO, NC): Connection for generator auto-start function
f	DRY(NO,NC): Reserved
g	CAN Matching resistance: Set DIP switch when use inverters in parallel
h	VIN/+12V: Connect an outside emergency switch on these 2 terminals
i	Meter 485B&485A: For Meter communication

3.4 PV Connection







PV connection of this hybrid inverter is same as traditional on-grid solar inverter (string inverter).

WARNING

* Please check the lowest ambient temperature of the location of the installation. The rated Voc on solar panel nameplate is obtained at 25°C. Solar panel Voc will increase with the decreasing of ambient temperature. Please ensure the Max.solar string voltage corrected at the lowest temperature not exceed the inverter max input voltage 550V for safe.

NOTICE

1. The inverter has two MPPTs. Both MPPT1 and MPPT2, users can connect 2 strings.
2. When users connect 2 strings to MPPT, make sure the two strings have same quantity of solar panels. The inverter will limit the total MPPT1 and MPPT2 input current to 25A/25A.
3. The inverter will limit the max. solar input power to 15kW for 10k model and 12kW for 7k and 8k model totally.

Cable Conductor Cross-Sectional Area	Cable model	Cable Voltage Withstand Requirements
5-9mm ²	10-8AWG	600V
1. Strip the cable insulation and install cold-pressed terminals 		2. Use a crimping tool to connect the terminals, ensuring that the cable cannot be pulled out after crimping. 
3. Assemble the cable into the positive and negative terminal casings, ensuring a secure connection. 		4. Tighten the sealing nut 
5. Check the polarity of the photovoltaic string cables and ensure that the maximum voltage does not exceed 550V. 		6. Ensure that all DC switches are in the “OFF” position and then insert the PV connector into the corresponding PV terminal in the inverters PV input terminal area. 

3.5 Battery Connection







3.5.1 Battery power cable connection

This part in this manual only describe the battery connection on inverter side, should you need more detailed information regarding the battery connection on battery side please refer to the manual of the battery.

Cable Requirement:	
Cross-section	35mm ² ×2 or 50mm ² ×1

● NOTICE

- Make sure that the inverter is powered off and there is no residual voltage at the battery interface. If the battery side line is connected, make sure that the battery is off.
- When the battery is charging and discharging, the current is big, please be sure to tighten the connection screws.
- Note that if there is a switch connected between the inverter and the battery, make sure that the switch is in the off state.
- Please note that there is a large current from the battery to the inverter, so it is recommended that the installation distance is not too far.


1. Unscrew the terminal head of the waterproof cover and pass the battery cable through the waterproof head and waterproof cover. 	2. Strip the insulation of the cable, Install heat shrink tubing and OT/DT terminal. 
3. Press the DT terminal sleeve wire barrel with hydraulic pliers to ensure that the wire and the terminal are firmly connected. 	4. Use a heat gun to fix the heat shrink tube. 
5. Fix the cables to the corresponding terminals according to the positive and negative polarities of the battery side (be sure to connect according to the correct polarity, reverse connection will cause damage to the converter and battery,) 	6. Tighten the sealing nut of the waterproof head. 

3.5.2 Battery communication cable connection



A correct battery communication cable must be used to connect the battery to the inverter when users choose lithium-ion battery type. Please select 'Lead-acid' type if the lithium battery can not communicate with inverter. The battery communication port on inverter is a RJ45 socket, Pin for the RJ45 plug of the communication cable is as below. Make the communication cable according to the below inverter Pin and the correct pinout of communication port on battery. The inverter supports both CAN and RS485 communication.

If using a Luxpower battery, select lithium type for option 6: Luxpower; for Hina battery, select lithium type option 1: Hina Battery.

Pin	Description
1	BAT RS485 B
2	BAT RS485 A
3	NC
4	BAT CAN H
5	BAT CAN L
6	NC
7	NC
8	NC



After connecting the battery power cable and communication cable, users are required to access the Advanced settings menu on the inverter LCD screen to select the battery type and brand.



● NOTICE

For Li-ion battery

1. Please make sure the lithium-ion battery to be used is compatible with inverters. Please contact your distributor for an updated battery compatible list.
2. If you are using multiple battery modules with the inverter, the inverter communication cable must be connected to the primary battery. Please check with your battery supplier for battery primary and subordinate settings.

For Lead-acid battery

1. The temperature sensor for the lead-acid battery is optional. If you need it, please contact the distributor for purchasing.
2. There are three stages for lead-acid battery charging. For charging/discharge related parameters, please check the charge /discharge settings page.

3.6 Grid & EPS load Connection

3.6.1 Grid regulation selection


Our inverters are compliant with on-grid regulations in several areas, including standards such as NRS 097, G99, G100, and more. When making the selection, please ensure alignment with the specific regulations in your area.

The screenshot shows the 'Basic' configuration tab of the inverter's control interface. The 'Grid type' is set to '230V' and 'Grid Freq' is set to '50'. The 'Grid regulation' is set to '3:SouthAfrica'. The 'Reconnect time(S)' is set to '0'. The 'Battery type' is set to '1: Lead-acid'. The 'Lithium brand' is set to '6:Lux'. The 'Lead capacity(Ah)' is set to '0'. The interface also includes buttons for 'Set', 'Basic', 'Charge', 'Discharge', 'Advanced', 'Debug', and 'Device info.'.

3.6.2 Grid and EPS load connection

The inverter can be connected to the load side of the service disconnecting means if the busbar rating in the main panel can meet the NEC705.12(B)(3) requirements. Otherwise, a Line side connection can be made to avoid an expensive main panel upgrade.

Grid and EPS Load Connection




3.6.3 AC cable connection


Cable Requirement:

Cable Size	Minimum Voltage
9-7 AWG(6-10mm²)	600V


Step 1: Installation of Grid Connector
Component Overview




Thread the AC cable through the cable seal and socket. Insert the conductors fully into the corresponding terminals of the terminal block and tighten the screws.



- b) Refer to the image to ensure correct AC cable connection.



- c) Assemble the Grid connector, ensuring that the ribs of the terminal block and the grooves on the housing are fully engaged until you feel or hear a distinct “click”.



Step2: Installation of LOAD Connector

- a) Align the LOAD connector with the AC terminals, and manually engage them until you hear or feel a distinct “click”.
- b) Install an AC circuit breaker (AC switch) between the inverter and the grid. Before connecting the AC cable from the inverter to the AC circuit breaker, ensure the AC circuit breaker is functioning properly. Close the AC circuit breaker and leave it in the open position.
- c) Connect the PE conductor to the grounding pole, and connect the N and L conductors to the AC circuit breaker.
- d) Connect the AC circuit breaker to the AC grid.
- e) Install a separate single-phase circuit breaker or other load disconnection device for each inverter to ensure safe disconnection under load.

● NOTICE

The inverter features residual current detection and protection functions. If the inverter must be equipped with an AC circuit breaker with residual current detection capability. An AC circuit breaker with a rated residual current greater than 300mA must be selected.

3.6.4 CT/Meter Connection


1. A single CT or single-phase meter needs to be installed
2. Standard provides a CT


CT Port Pin definition

The CT port for connecting the CT is an RJ45 port. We have equipped the CT with an RJ45 plug, pre-configured with the appropriate CT ratio in Charge Vpv start (V), so you can connect it directly to the port.

Pin	Description
1-4	reserve
5	CT2 N
6	CT2 P
7	Grid CT N
8	Grid CT P

Pin12345678





Please refer to the above connection diagram for the correct positions of CT. The arrows on the CT must point to inverter side.



CT Clamp Ratio


The Luxpower inverters support two ratios of CT clamp-1000:1, 2000:1 and 3000:1. The CT ratio of the CT in the accessory bag is 1000:1. If you are using a 3rd party CT, please ensure the CT ratio is either 1000:1, 2000:1 or 3000:1 and then select the correct CT ratio setting in the inverter monitor page or on inverter LCD.

Extend CT clamp cable

CT/Meter Connection

The CT wires can be extended with a common ethernet cable if the length is not enough. A RJ45 adapter is needed for the extending. The CT wires can be extended up to 300ft (around 100m).






Meter Connection

Currently only EASTRON Modbus version meters can be used. If you need to use meter for import/export detection instead of CT, you need to connect it to the Meter 485A and 485B terminals on the inverter, please contact Luxpowertek for detailed guideline.

3.7 Working with Generator

3.7.1 Generator system connection

This hybrid inverter can work with generator. There are Gen port on the inverter for generator connection.



3.7.2 Generator Startup and Stop settings

The top screenshot shows the 'Basic' tab with the following settings:

- Operating Mode: Use SOC % ☒ Use Bat V ☐ Set
- Bat charge current limit(A):
- AC charge ☒ According to SOC/Volt ☐ Set
- AC charge power(kW): Start AC charge SOC(%):
- Time 1: Start AC charge Volt (V):
- Time 2: Stop AC charge SOC(%):
- Time 3: Stop AC charge Volt (V):

The bottom screenshot shows the 'Generator' settings with the following settings:

- Charge current limit(A): Gen rated power(kW): Set
- Charge start Volt(V): Charge start SOC(%):
- Charge end Volt(V): Charge end SOC(%):
- AC couple:
- Start Volt(V): Start SOC(%): Set
- End Volt(V): End SOC(%):

It depends on the Bat operating mode setting, The system will use either battery SOC or battery voltage to determine whether the system needs to start or stop the generator.

Generator Start Conditions

When utility fails and

-When battery is discharged to cut-off settings

or there is force charge request from battery.

or when the battery voltage or SOC is lower than the Generator Charge start Volt/SOC settings,


Generator Stop Conditions

when battery voltage or SOC is higher than Charge end Volt/SOC settings value.

3.8 AC Coupling Installation Connection

The inverter supports AC coupling connection with existing on-grid solar system. The existing solar system is connected to the inverter's GEN port.


Connection for AC coupled solar system



After AC couple function enabled:

When the grid is on: The GEN terminal is connected to the grid terminal inside the inverter, the hybrid inverter will work in conjunction with the on-grid inverter to supply power to loads, charge batteries, any remaining energy will be exported to the grid.

When the grid is off: The GEN terminal is connected to the LOAD terminal inside the inverter. In this scenario, the loads will be primarily supplied by solar power. If the solar panels generate more power than the load consumption, the excess solar power will be stored in the battery. When solar power exceeds the combined power demand of the loads and the maximum battery charging power (e.g., when the battery is nearly full), the inverter will signal the on-grid inverter to reduce power via the frequency shifting power reduction mechanism. This helps maintain the balance between generation and consumption within the micro-grid system.




3.9 Parallel System Connection


3.9.1 Connection for paralleling system

The hybrid inverter supports parallel connection to expand power and energy capacity to suit different using scenarios.

The system connection for single-phase paralleling is as below:




The system connection for three-phase paralleling is as below:



Please put the 2-bit CAN balancing resistor switch to ON status for the first and end inverter of the daisy chain loop.

Please put the CAN communication PIN to ON status for the first and the end inverter



If the parallel cable is not enough or long enough, please make a straight pin to pin cable

Settings for paralleling function in monitor system

1. Set up monitoring for the system, add all dongles into one station. Users can login to visit the monitor system, Configuration->Station->Plant Management->Add dongle to add dongles.

LU X POWER TEK

Monitor Data Configuration Overview Maintenance

Asia English shawou distributor

Stations

+ Add Station

Search by station name

	Plant name	Installer	End User	Country	Timezone	Daylight saving time	Create date	Action
Dongles	1	Genesis		South Africa	GMT+2	No	2019-03-14	Station Management
Devices	2	Butler Home	Elangeni	Aspergo Install	South Africa	GMT+2	2019-03-25	Station Management
Users	3	Office		johnbutler	South Africa	GMT+2	2019-06-03	Station Management
Operation Record	4	Cronje Home	Broomhead		South Africa	GMT+2	2019-07-16	Station Management

cronje

2. Enable share battery for the system if the system share one battery bank, otherwise disable the shared battery function

Monitor

Data

Configuration

Overview

Maintenance

Asia

English

Shawou distributor

Stations Overview

Station Name

Search by inverter SN


Device Overview

	Serial number	Status	Solar Power	Charge Power	Discharge Power	Load	Solar Yield	Battery Dischar	Feed Energy	ConsumptionEr	Station name	Parallel	Action
1	0272011008	Normal	228 W	42 W	0 W	182 W	215.3 kWh	39.6 kWh	0 kWh	551.2 kWh	Dragonview	A-1	Parallel
2	0272011011		35 W	32 W	0 W	0 W	158.7 kWh	21.1 kWh	0 kWh	160.5 kWh	Dragonview	A-2	Parallel
3	0272011012		1 kW	129 W	0 W	1 kW	170.3 kWh	49.9 kWh	0 kWh	434.5 kWh	Dragonview	A-3	Parallel
4	0272011017		79 W	48 W	0 W	106 W	99 kWh	85.6 kWh	0 kWh	257.1 kWh	Dragonview	A-4	Parallel

Please contact your inverter supplier for more detailed guidance for paralleling system

3.10.1 Wifi/2G/4G/WLAN dongle connection

To view data on smartphone, please download the LuxPower APP from Google Play or Apple APP store, then login with the user account.



3.10.2 Setup the monitor system

1. Sign up an account on the mobile phone APP or Website

The "customer code" is a code we assigned to your distributor or installer. You can contact your supplier for their code.

The left screenshot shows the login/register screen of the mobile app. It features a green header with the LUXPOWER logo. Below the header, there are input fields for 'Username' and 'Password', a checkbox for 'Remember username', and a checkbox for 'Auto login'. A green 'LOGIN' button is present, along with a link for 'Forget password?'. Below a separator line, there are four buttons: 'REGISTER' (highlighted with a red box), 'DONGLE CONNECT', 'PRODUCT WARRANTY', and 'LOCAL CONNECT'. At the bottom, there is a 'DOWNLOAD FIRMWARE' button and the version number 'Version 3.0.2'.


The right screenshot shows the registration form. It has a green header with a back arrow. The form includes fields for: '* Cluster' (set to 'Europe'), '* Username', '* Password', '* Repeat password', 'Real name', '* E-mail', 'Tel number', '* Station name', '* Daylight saving time' (toggle switch), '* Continent' (set to 'Asia'), '* Region' (set to 'East Asia'), '* Country' (set to 'China'), '* Timezone' (set to 'GMT +8'), 'Address', '* Customer code (Distributor/installer code)', '* Dongle SN' (highlighted with a red box), and '* Dongle PIN' (highlighted with a red box). A green 'REGISTER' button is at the bottom.

2. Create station and add dongle for the station

The screenshot shows the 'add station, add wifi module' screen. At the top, there is a green header with a plus icon and the text 'add station, add wifi module'. Below the header is a search bar labeled 'Station name / Serial number'. The main content area lists several stations with their names, status, and 'EDIT' and 'ADD DONGLE' buttons. The stations are: 9Belvmarcia (Normal), Juan M Orcera Siñeriz (Normal), Isabella (Normal), Daryl (Notice), Ken Grey (Normal), slave (Offline), pichy home (Normal), and Christopher Lyew (Normal). A red box highlights the 'ADD DONGLE' button for the 'slave' station. At the bottom, there is a pagination bar showing '1'.

3.10.3 Set homewifi password to dongle

1. Connect your mobile phone to the "BAxxxxxxx" wireless network where "BAxxxxxxx" is the serial number of the WiFi dongle.
2. Click the "WiFi MODULE CONNECT" button on the APP
3. Select the home WiFi that the WiFi dongle is to be connected to, enter the WiFi's password. And then click "HomeWifi Connect". The WiFi dongle will restart and try to connect to our server automatically
4. Check the LEDs' status on the WiFi dongle. The middle light should be solid lit when the WiFi dongle connects to our server successfully



5. Now you can disconnect your mobile phone from the "BAxxxxxxx" wireless network. Login on the APP with your account, you'll find the inverter information already appears. Now you'll be able to monitor and control the inverter remotely on any smart phone or computer that has Internet connection.

Please download the following guides for setting up WiFi dongle and monitoring account at Document Reference:

- 1. Wifi Quick Guidance
Quick guidance for setting connection of WiFi module to home WiFi, you can also find a printed version in the packaging of the WiFi module.
- 2. Monitor system setup for Distributors and Monitor system setup for endusers
Account registration, the description of each items and parameters, setting parameters
- 3. Lux_Monitor_UI_Introduction
Introduction of monitor interface


3.10.4 Third party RS485 communication

Note: This feature is designed specifically for third-party users who wish to use their own monitoring systems. If you plan to undertake independent development, please ensure to contact your distributor to obtain the RS485 communication protocol.

The following two interfaces can be utilized for communication:

Meter 485B and 485A Interfaces: When the entire system is not connected to the meter, these two pins can be used to communicate with the inverter.

INV485 Interface: As this interface is shared with the WIFI module, it can only be used to communicate with the inverter when the WIFI module is not in use.



4. Operation Guide

4.1 Operation Mode and Function

The inverter has different working modes to meet customers' various demands, the working modes are as below:

4.1.1 Self-consumption Mode (Default)

In this mode, the priority order of load supply source is Solar > Battery > Grid. The priority order of solar power usage is Load > Battery > Grid.



Application Scenarios

Self consumption mode will increase self consumption rate of solar power and reduce the electricity bill significantly

Related Settings

Effective when Charge Priority, AC Charge, and Forced discharge are disabled

Example




4.1.2 Charge First Mode

The priority order of solar power usage will be Battery >Load >Grid. During the Charge Priority time period, load is first supplied with grid power. If there is excess solar power after battery charging, the excess solar power will take load together with grid power.


Application Scenarios

When users want to use solar power to charge batteries, grid power is used to supply loads.

Related Settings



Example



4.1.3 AC Charge Function

(Notes: During the AC charging time period, the battery does not discharge.)

Users can charge battery with grid power when electricity price is cheap, and discharge battery power to supply load or export to the grid when electricity price is high.

Application Scenarios


When users have a Time of Use(TOU) rate plan.

Related Settings

4.1.4 Grid peak-shaving Function

- **Grid peak-shaving & Grid peak-shaving power(kW):**
Is used to set the maximum power that the inverter will draw from its grid power. And the Peak-shaving power needs to be set to more than 0.2(KW)

4.1.5 Smart load Function



● **Smart Load:**

This function is to make the Gen input connection point as an load connection point, if you enable it, inverter will supply power to this load when the battery SOC and PV power is above a user setup value. e.g. Smart load start SOC=90%, Smart load end SOC=85%, Start PV power=300W, it means: When the PV power exceeds 300W, and the battery system SOC gets to 90%, the Smart Load Port will switch on automatically to supply the load which is connected on this side. When the battery reaches SOC<85% or PV power<300w, the Smart Load Port switch off automatically.

Note:

If you enable the Smart load function, it's forbidden to connect the generator at the same time, otherwise the device will be damaged!


4.2 LCD Display

Users can view inverter running status, real time power, daily and accumulated energy information conveniently on inverter LCD. In addition to the above information, users can also check alarm and fault record on the display for troubleshooting.

4.2.1 Viewing information and alarm/fault record

Home Page

Touch the screen to light it up if it's in sleep mode. The Home page will appear on the display. Users will see a system overview diagram along with the real time information of each component, such as battery SOC, battery charging/discharging power, grid import/export power, load power, etc. On the right part of the screen, users can check daily and accumulated solar energy, battery charged/discharged energy, grid imported /exported energy, as well as load consumption.



Detailed System Information

Click on the pie icon at the bottom of the screen and, you'll be able to view the detailed real time solar information, battery information, grid information and EPS output information.

Solar	Vbat		Ibat	
Battery	Pchg		Pdischg	
Grid	Vbat_inv		BatState	
UPS	SOC/SOH		CycleCnt	
Other	Vchgrf/Vcut		Bat capacity	
	I maxchg		I maxdischg	
	Vcellmax		Vcellmin	
	Tcellmax		Tcellmin(°C)	
	BMSEvent1		BMSEvent2	
	Echg_day		Edischg_day	
	Echg_all		Edischg_all	

Solar	Vpv1		Ppv1	
Battery	Vpv2		Ppv2	
Grid				
UPS	Epv1_day		Epv1_all	
Other	Epv2_day		Epv2_all	

Solar	Vgrid		Fgrid	
Battery	VgridL1N		VgridL2N	
Grid	Vgen		Fgen	
UPS	Pimport		Pexport	
Other	Pinv		Prec	
	Pload			
	Eimport_day		Eexport_day	
	Eexport_all		Eexport_all	
	Einv_day		Erec_day	
	Einv_all		Erec_all	
	Eload_day		Eload_all	

Solar	Vups		Fups	
Battery	VupsL1N		VupsL2N	
Grid	Pups		Sups	
UPS	PupsL1N		SupsL1N	
Other	PupsL2N		SupsL2N	
	Eups_day		Eups_all	
	EupsL1N_day		EupsL1N_all	
	EupsL2N_day		EupsL2N_all	


Solar	Status		StatusPre	
Battery	SubStatus		SubStatusPre	
Grid	FaultCode		AlarmCode	
UPS	Vbus1/Vbus2		VbusP/VbusN	
Other	T0/T1(°C)		T2/T3(°C)	
	OCP/Grid OnOff Cnt		ExitReason1/2	
	InnerFlag/RunTrace		NoDis/chgReason	
	Dis/chg LimitReason		Dis/chg CurrLimit	
	Inv/Rec LimitReason		Inv/Rec CurrLimit	
	Para status			

Fault/Alarm Information

Touching the bell icon at the bottom of the screen, you'll see all the current and historical fault & warning information on this page.

Fault status	M3 Rx failure	Model fault	Eps short circuit
Alarm status	Eps power reversed	Bus short circuit	Relay fault
Fault record	M8 Tx failure	M3 Tx failure	Vbus over range
Alarm record	Eps connect fault	PV volt high	Hard over Curr
	Neutral fault	PV short circuit	Temperature fault
	Bus sample fault	Inconsistent	M8 Rx fault
	Para Comm error	Para master loss	Para rating Diff
	Para Spec Diff	ParaPhase set error	Para Gen unAccord
	Para Sync loss	Fault A	Fault B
	Fault C	Fault D	Fault E

Fault status	Bat Com failure	AFCI Com failure	AFCI high
Alarm status	Meter Com failure	Bat fault	Auto test failure
Fault record	Lcd Com failure	Fw mismatch	Fan stuck
Alarm record	Bat reversed	Trip by no AC	Trip by Vac abnormal
	Trip by Fac abnormal	Trip by iso low	Trip by gfci high
	Trip by dci high	PV short circuit	GFCI module fault
	Bat volt high	Bat volt low	Bat open
	Offgrid overload	Offgrid overvolt	Meter reversed
	Offgrid dcv high	RSD Active	Alarm A
	Para Phase loss	Para no BM set	Para multi BM set



4.2.2 Setting Parameters

Clicking on the gear icon at the bottom of the screen, you'll get into the parameter setting page of the inverter.

a. Basic settings

- **Standby:**
Is for users to set the inverter to normal status or to standby status. In standby status, the inverter will stop any charging or discharging operations, as well as solar-feed-in.
- **Restart inverter:**
Restart the system, please note the power maybe interrupted when restarted.

b. Charge setting

- **Operating Mode :**
Users can decide to use SOC or BatV to control charge and discharge logic depending on battery type.
- **Bat charge current limit(A):**
Users can set Max charge current.
- **AC Charge:**
If users want to use grid power to charge their battery, then they can enable "AC Charge", set time periods when AC charging can happen, AC Charge power(kW) to limit utility charging power, and "Stop AC Charge SOC(%)" as the target SOC for utility charging. "Stop AC Volt(V)" as the target battery voltage for utility charging.

- Charge first:**
 PV charge configuration. When using enable Charge first, PV will charge the battery as a priority, set time periods when PV charge can happen, charge first power(kW) to limit PV charge power, and "Charge first SOC(%)" as the target SOC for PV charge first. "Charge first Volt(V)" as the target battery voltage for PV Charge first.
- Lead acid:**
 When using Lead-acid battery, you need to set parameters in these programs, Follow the battery manufacturer's recommendation.

- Generator:**
 - Bat charge current limit(A):** Set the Max. battery charge current from the Generator. The Generator will start charging according to the Charge start Volt/SOC, and stop charging when the battery voltage or SOC reaches the Charge end Volt/SOC value.
 - Gen rated power:**
 Enter the rated power of the generator after connecting it.

c. Discharge setting

- Discharge current limit(A):**
 The Max. discharge current from battery
- Discharge start power(W):**
 The Min. value can be set to 50. When the inverter detects the import power is higher than this value, battery start discharging, otherwise battery will keep standby
- On-grid Cut-off(%) and Off-grid Cut-off(%) / On-grid Cut-off(V) and Off-grid Cut-off(V):**
 End of discharge SOC/Cut off voltage in on-grid and off-grid condition respectively.
- Forced discharge:**
 Settings for battery force discharge within certain time period. In the preset time period, the inverter will discharge battery at the power set by "discharge power", until battery SOC or voltage reaches "Stop discharge" value.

- Operating Mode**
 You can choose "Use SOC %" or "Use Bat V" to control the battery discharge state

d. Advanced setting

● Grid type:

You can choose by yourself, 240/120V, 208/120V,

● Battery type:

No battery, lead-acid or lithium-ion.

- If lead-acid battery is selected, please input correct battery capacity
- If lithium-ion battery is selected, please choose the battery brand in the Lithium brand drop down list.

● Offgrid output:

It is for users to set if the inverter provides backup power or not when the grid is lost. If users want the load to be seamlessly transferred to the inverter backup power, "Seamless switch" must be enabled. If customers don't have a battery installed yet, but still wish to have inverter backup power with only solar panels connected, "PV Grid Off" can be enabled to use solar power to supply load when the grid fails or load-shedding happens. Micro-grid: only needs to be set when the generator is connected to the inverter's grid port. With this option enabled, the inverter will use AC power to charge the battery and won't export any power through the grid port if AC power is present at the inverter's grid port.

● CT direction reversed:

If the CT are in a wrong direction which will cause the display to show incorrect information and features of the inverter will not function correctly, the installer can modify it by selecting it (only for direction not CT placement), there is no need to reconnect the CT and no need to go change it physically, in the order of loads--grid export--battery charging.

The supported CT ratio is 1000:1, 2000:1 and 3000:1. default CT ratio is 1000:1. If 3rd party CT is to be used, please ensure its CT ratio is one of them, and set it accordingly. The battery brand in the Lithium brand drop down list.

- **Meter type:** Please select it according to the meter that's to be installed.
- **Charge last:** When users want to use solar power in the order of loads -- grid export -- battery charging.

● Export to Grid:

This function allows users to enable a zero export feature. If exporting solar power is not permitted, users should disable the "Export to Grid" option. In cases where even a small amount of solar export triggers a trip in the utility meter, "Zero Export" can be enabled. With this setting, export detection and adjustment will occur every 20, milliseconds, effectively preventing any solar power from being exported. If export is allowed, users can enable "Export to Grid" and set a maximum allowable export limit in "Max Export to Grid(kW)."

- **Role:** The Role setting of the parallel system. It is set to 1 phase primary by default. In a parallel system, only one inverter is allowed to be set as Primary, and the others are all Subordinate.
- **Share battery:** When the inverter is connected as a parallel system, all inverters need to share the battery, and set the "Share Battery" to "Enable" at the same time

- **Phase:** This is the phase code setting of the LOAD output. The system will automatically detect the phase sequence of the inverter (consistent with the phase sequence of the connected Grid mains) and display on the inverter after it is connected to the grid

4.3 Start-up and shut down the inverter

4.3.1 Start up the inverter

Step 1. Turn on the battery system firstly, then turn on the DC breaker between battery and inverter.

Step 2. Make sure the PV voltage of the strings are higher than 120V, and check if the inverter works in PV charge or PV charge back-up mode.

Step 3. Make sure step 1 and 2 above work properly before turning on the grid power or generator breaker, and check if the inverter can go to bypass mode and on-grid mode normally.

4.3.2 Shut down the inverter

If there is an emergency issue that necessitates shutting down the inverter, please follow the steps outlined below. **Danger:** when operating under load, please refrain from attempting to use a direct connection method to the terminals of the battery, PV, and AC input for shutting down the inverter.

Step 1. Turn off the Grid breaker of the inverter.

Step 2. Switch off the load breaker.

Step 3. Turn off PV breaker and then battery breaker, waiting for the LCD to go off.

5. Troubleshooting & Maintenance

5.1 Regular Maintenance

• Inverter Maintenance

a. Check the inverter every 6 months or 1 year to verify if there are damages on cables, accessories, terminals and the inverter itself.	b. Check the inverter every 6 months to verify if the operating parameter is normal and there is no abnormal heating or noise from the inverter.
c. Check the inverter every 6 months to confirm there is nothing that covers the inverter heat sink, if there is, shut-down the inverter and clear the heat sink.	

• Battery Maintenance

Follow the manufacturer's requirements on maintenance. When you carry out these works on batteries, please make sure to fully shut-down the inverter for safety consideration.

5.2 LED Displays


LED	Display	Description	Suggestion
Green LED	Solid lit 	Working normally	
	Flashing 	Firmware upgrading	Wait till upgrading complete
Yellow LED	Solid lit 	Warning, inverter working	Need troubleshooting
Red LED	Solid lit 	Fault, inverter stop work	Need troubleshooting

5.3 Troubleshooting Based On LCD Displays

Once there is any warning or fault occurring, users can troubleshoot according to the LED status and the warning/fault information on the LCD.

1. Fault on the LCD


If the dot on the left of fault item is red, it means the fault is active. When it is grey, it means the fault is defective.



Fault Code	Fault	Meaning	Troubleshooting
E00	M3 Rx failure	M3 microprocessor fails to receive data from DSP	Restart inverter, if the error still exists, contact Luxpower service or your inverter supplier.
E01	Model fault	Incorrect model value	
E12	LOAD short circuit	Inverter detected short-circuit on LOAD output terminals	1. Check if the L1, L2 and N wires are connected correctly at inverter LOAD output port; 2. Disconnect the LOAD breaker to see if fault remains. If fault persists, contact Luxpower service or your inverter supplier.
E13	LOAD power reversed	Inverter detected power flowing into LOAD port	Restart inverter, if the error still exists, contact Luxpower service or your inverter supplier.
E14	Bus short circuit	DC Bus is short circuited	
E16	Relay fault	Relay abnormal	
E17	M8 Tx failure	DSP fails to receive data from M8 microprocessor	
E18	M3 Tx failure	DSP fails to receive data from M3 microprocessor	
E19	Vbus over range	DC Bus voltage is too high	Please check if the PV string voltage is within the inverter specification. If string voltage is within range, and this fault still appears, contact Luxpower service or your inverter supplier.
E20	LOAD connect fault	LOAD port and grid port are connected mixed up	Check if the wires on LOAD port and grid port are connected correctly. If the error exists, contact Luxpower service or your inverter supplier.
E21	PV volt high	PV voltage is too high	Please check if the PV string voltage is within the inverter specification. If string voltage is within range, and this fault still appears, contact Luxpower service or your inverter supplier.
E22	Hard over curr	Hardware level over current protection triggered	Restart inverter, if the error still exists, contact Luxpower service or your inverter supplier.
E23	Neutral fault	Voltage between N and PE is greater than 30V	Check if the neutral wire is connected correctly.
E24	PV short circuit	Short circuit detected on PV input	Disconnect all PV strings from the inverter. If the error persists, contact Luxpower service or your inverter supplier.
E25	Temperature fault	Heat sink temperature is too high	Install the inverter in a place with good ventilation and having no direct sunlight. If the installation site is okay, please check if the NTC connector inside the inverter is loose.
E26	Bus sample fault	Inverter detected DC bus voltage lower than PV input voltage	Restart inverter, if the error still exists, contact Luxpower service or your inverter supplier.
E27	Inconsistent	Sampled grid voltage values of DSP and M8 microprocessor are inconsistent	
E31	M8 Rx fault	M8 microprocessor fails to receive data from DSP	

2. Alarm on the LCD

If the dot on the left of fault item is yellow, it means the fault is active. When it is grey, it means the fault is deactive



Warning Fault	Fault	Meaning	Troubleshooting
W00	Bat com failure	Inverter fails to communicate with battery	Check if communication cable is correct, and if you have chosen the correct battery brand on inverter LCD. If all is correct but this error persists, please contact Luxpower service or your inverter supplier.
W03	Meter com failure	Inverter fails to communicate with the meter	1. Check if the communication cable is connected correctly and in good condition. 2. Restart inverter. If the fault persists, contact Luxpower service or your inverter supplier.
W04	Bat Fault	Battery cannot charge or discharge	1. Check the battery communication cable for correct pinout on both inverter and battery end; 2. Check if you have chosen an incorrect battery brand; 3. Check if there is fault on battery's indicator. If there is fault, please contact your battery supplier.
W05	Auto test failure	Auto test failed	Only applied to Italy model
W07	Lcd com failure	LCD fails to communicate with M3 microprocessor	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
W08	Fwm mismatch	Firmware version mismatch between the microprocessors	
W09	Fan stuck	Cooling fan(s) are stuck	
W21	Trip by gfcI high	Inverter detected leakage current on AC side	1. Check if there is ground fault on grid and load side; 2. Restart inverter. If the fault remains, contact Luxpower service or your inverter supplier.
W22	Trip by dci high	Inverter detected high DC injection current on grid port	Restart inverter. If the fault remains, contact Luxpower service or your inverter supplier.
W23	PV short circuit	Inverter detected short circuited PV input	1. Check if each PV string is connected correctly; 2. Restart inverter. If the fault remains, contact Luxpower service or your inverter supplier.

W24	GFCI module fault	GFCI module is abnormal	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
W25	Bat volt high	Battery voltage is too high	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
W26	Bat volt low	Battery voltage is too low	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
W27	Bat open	Battery is disconnected from inverter	Restart inverter. If fault still exists, contact
W28	Offgrid overload	Overload on EPS port	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
W29	Offgrid overvolt	EPS voltage is too high	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.

PV Input data	GEN-LB-EU 7K	GEN-LB-EU 8K	GEN-LB-EU 10K
Max. usable input current(A)	25/25	25/25	25/25
Max. short circuit input current(A)	34/34	34/34	34/34
Start input voltage(V)	100	100	100
Startup voltage(V)	140	140	140
Full power MPPT voltage range(V)	170-480	170-480	200-480
DC nominal voltage(V) MPPT tracker	360	360	360
DC voltage range(V)	100-600	100-600	100-600
MPPT operating voltage range(V)	120-500	120-500	120-500
Max. power(W)	12000	12000	15000
Number of MPPT	2	2	2
Inputs per MPPT	2/2	2/2	2/2
Grid Input/ output data			
Nominal Output Current(A)	30.4	34.8	43.8
Max. Output Current(A)	38.5	38.5	47.8
Rated voltage(V)	230	230	230
Operating voltage range(V)	180-270	180-270	180-270
Nominal power output(W)	7000	8000	10000
Operating frequency(Hz)	50/60	50/60	50/60
Operating frequency range(Hz)	45-55/55-65	45-55/55-65	45-55/55-65
Phase shift	0.99@full load	0.99@full load	0.99@full load
Reactive power adjust range	-0.8~+0.8 leading Adjustable	-0.8~+0.8 leading Adjustable	-0.8~+0.8 leading Adjustable
THDI	<3%	<3%	<3%
Sync inrush current(A)	35	35	35
UPS AC output data			
Nominal output current(A)	30.4	34.8	43.8
Nominal output voltage(V)	230	230	230
Rated output power(VA)	7000	8000	10000
Operating frequency(Hz)	50/60	50/60	50/60
Peak power(VA)	2xPn, 0.5s	2xPn, 0.5s	2xPn, 0.5s
THDV	<3%	<3%	<3%
Switching Time	<20	<20	<20
Efficiency			
Europe Efficiency	96%	96%	96%
Max. Efficiency @ PV to grid	97.5%	97.5%	97.5%
Max. Efficiency @ battery to grid	94%	94%	94%
MPPT Efficiency	99.9%	99.9%	99.9%
Battery data			
Type	Lead-acid battery/Lithium battery	Lead-acid battery/Lithium battery	Lead-acid battery/Lithium battery
Max. charge current(A)	146	167	208
Max. discharge current(A)	146	167	208
Nominal voltage(V)	48	48	48
Voltage range(V)	40-60	40-60	40-60
Max. voltage(V)	60	60	60
General Data			
Integrated disconnect	DC switch	DC switch	DC switch
Reverse polarity protection	Yes	Yes	Yes
DC switch rating for each MPPT	Yes	Yes	Yes
Output over-voltage protection	Yes	Yes	Yes
Output over current protection	Yes	Yes	Yes
Ground fault monitoring	Yes	Yes	Yes
Grid monitoring	Yes	Yes	Yes
Pole sensitive leakage current Monitoring unit	Yes	Yes	Yes
Dimensions(mm)	566*536*290mm(22.3*21.1*11.4inch)		
Weight(kg)	42.64kg(93.8lbs)		
Degree of protection	NEMA4X/IP65	NEMA4X/IP65	NEMA4X/IP65
Cooling concept	Smart cooling	Smart cooling	Smart cooling
Topology	Transformer-less	Transformer-less	Transformer-less
Relative humidity	0-100%	0-100%	0-100%
Altitude(m)	<2000m	<2000m	<2000m
Noise emission(dB)	<50dB	<50dB	<50dB
Internal consumption(W)	<15W	<15W	<15W
Display	Touch color screen	Touch color screen	Touch color screen
Communication interface	Rs485/Wi-Fi/CAN	Rs485/Wi-Fi/CAN	Rs485/Wi-Fi/CAN
Standard warranty	5years	5years	5years

[illegible]

[illegible]

■ YOUR RELIABLE ENERGY SOLUTION PARTNER



Lux Power Technology Co., Ltd
Headquarter: +86 755 8520 9056
www.luxpowertek.com
Contact us: info@luxpowertek.com



092.20039AC